



wateroam[®]

ROAMfilter Plus User Guide
Maintenance: Pre-filter Cleaning


© 2020

BUILDING A WORLD WITHOUT PROLONGED THIRST


Overview



6 maintenance processes to follow for good continued operation:



Recommended maintenance frequency:




*Disclaimer: product maintenance may vary based on context

Purpose of Pre-filter Cleaning




- **Purpose of Pre-filter:** To block out large debris from entering the filter.
- Cleaning the Pre-filter ensures that large debris do not clog the inlet of the filter. That prevents the build up of pressure and keeps the flow rate at the optimal level.




Key Components of the ROAMfilter Plus:

Front View





Back View



Note: A detailed version can be found in your ROAMfilter Plus Instruction Manual



Key Components of the ROAMfilter Plus:



Note: A detailed version of the Key Components can be found in your ROAMfilter Plus Instruction Manual

Video Tutorial: Pre-filter Cleaning

[Click here for the : ROAMfilter™ Plus Pre-filter Cleaning video](#)




Wash the Pre-filter in a small bucket of clean water

Pre-filter Cleaning

Important pointers:

1. Once per week.
2. Replaced once every 3-4 months.



Thank You

Any questions?

Contact details:

Phone number: +65 6303 0603

Email: support@wateroam.com